



Accessories for testo 175 and 177

testo 575 fast printer

- Fast-action print mechanism, 6 lines/s
- Prints tables/graphics
- Brief info. or full memory can be printed as required
- Determine section to be printed
- Your language can be set
- Self-adhesive Testo paper can also be used



Fast printout and logger rebooting with testo 575

Part no. 0554 1775

testo 580 data collector

- Can read out up to 25 full testo 175 loggers or 10 full testo 177 loggers
- Displays all status information
- Download collected data to PC using Testo ComSoft 3



The testo 580 data collects data on site for upload to PC and analysis

RS232 Version
Part no. 0554 1778
USB version
Part no. 0554 1764

testo alarm modem GSM

Alarm notification by SMS or e-mail
 Do you require remote control of the measuring instrument, i.e. without the need to be on site? The Testo alarm modem (GSM) is attached to the portable instrument and offers the following functions:

- Alarm by SMS/fax/e-mail which is sent when limit values are exceeded or the status changes.
- Remote query of readings by mobile phone.
- Remote readout of stored data into the ComSoft software.


Part no. 0554 0522

testo 581 alarm signal output

- Transmission of alarm messages – e.g. when programmed limit values in the data logger are exceeded – to external components such as horns, lamps, PLC etc.
- Signal transfer via floating signal output

Part no. 0554 1769

Ethernet adapter

- Fast transfer of readings
- Use of an existing network without additional cabling
- Long transmission paths
- Identification of measuring instruments in system network
- In connection with ComSoft 3

Part no. 0554 1711

Printer and Accessories	Part no.
Fast testo 575 printer, incl. 1 roll of thermal paper and batteries, infrared thermal line printer with graphics function	0554 1775
Spare thermal paper for printer (6 rolls)	0554 0569
Spare thermal paper for printer (6 rolls), measurement data documentation legible for up to 10 years	0554 0568
Label thermal paper (Testo patent) for testo 575 printer (6 rolls), can be applied directly	0554 0561
Additional accessories	Part no.
testo 580 data collector set with RS232, readout holders included, for testo 175/177 data loggers	0554 1778
testo 580 data collector set with USB, readout holders included, for testo 175/177 data loggers	0554 1764
testo 581 alarm signal output, floating, for testo 175/177, forwards information efficiently when limits are exceeded to e.g. horns, lamps, PLC etc.	0554 1769
Battery, 3.6 V/1.9 Ah 1AA, for testo 175-T1/175-T2 and all testo 177 loggers	0515 0177
Battery, 3.6 V/1.9 Ah 1AA, for testo 175-T1/175-T2 and all testo 177 loggers	0515 0177
Transport and Protection	Part no.
Lock for wall holder for testo 175/177 data loggers	0554 1755
Transport case for up to 5 testo 177 data loggers, testo 575 printer, testo 580 data collector and accessories	0516 1770
Accessories for humidity probes	Part no.
testo saline pots for control and humidity adjustment of humidity probes, 11.3 %RH and 75.3 %RH with adapter for humidity probe	0554 0660
Metal protection cage, Ø 12 mm for humidity probes, for measurement in flow velocities of less than 10 m/s	0554 0755
Cap with wire mesh filter, Ø 12 mm	0554 0757
Teflon sintered filter, Ø 12 mm, for corrosive substances, high humidity range (long-term measurements), high velocities	0554 0756
Stainless steel sintered cap, Ø 12 mm, is screwed onto humidity probe, for measurements at high flow velocities or in contaminated air	0554 0647

Software	Part no.
For testo 175: ComSoft 3 Set - Basic with RS 232 interface, Basic software with diagram and table function, incl. desk-top holder, PC connection cable	0554 1759
For testo 175: ComSoft 3 Set - Basic with USB interface, Basic software with diagram and table function, incl. desk-top holders, PC connection cable	0554 1766
For testo 177: ComSoft 3 Set - Basic with RS 232 interface, Basic software with diagram and table function, incl. desk-top holder, PC connection cable	0554 1774
For testo 177: ComSoft 3 Set - Basic with USB interface, Basic software with diagram and table function, incl. desk-top holders, PC connection cable	0554 1767
ComSoft 3 - Professional with data management, incl. database, analysis and graphics function, data analysis, trend curve (without interface)	0554 0830
ComSoft 3 - For requirements to CFR 21 Part 11, incl. database, analysis and graphics function, data analysis, trend curve (w/o interface)	0554 0821
RS232 interface for testo 175/177 incl. desk-top holders, PC connection cable, (please also order for ComSoft 3 - Professional)	0554 1757
USB interface, for testo 175/177 incl. desk-top holders, PC conn. cable, (Please order with ComSoft 3 - Professional)	0554 1768
Ethernet adapter, RS232 - Ethernet incl. software driver, mains unit, facilitates data communication in network	0554 1711
Testo alarm modem GSM	Part no.
Alarm modem GSM	0554 0522
Software Testo Alarm-Editor Professional AK20	0554 0519
Software Testo Alarm-Editor Basic AK4	0554 0518
Stick aerial for screwing in	0554 0523
Magnetic foot aerial with 3 m cable	0554 0524
Mains unit (rail mounting) 90 to 264 VAC/ 24 VDC (2.5A)	0554 1749
Mains unit	0554 1142
Serial interface cable (RS232) for initial parameterization of the alarm modem	0449 0051
Calibration Certificates	Part no.
ISO cal. cert./humidity, humidity data logger; calibration points 11.3%RH and 75.3%RH at +25°C	0520 0076
DKD calibration cert./humidity, humidity data logger; cal. points 11.3%RH and 75.3%RH at +25°C	0520 0246
ISO calibration certificate/temperature, Surface in refrigerator, measurement points -18 °C; 0 °C; +60 °C	0520 0151
DKD calibration certificate/temperature, temp. data logger; cal. points -20°C; 0°C; +60°C	0520 0261