


Supplement

Title: 113 Instruction Sheet	Supplement Issue: 4
Part Number: 3083192	Issue Date: 2/14
Print Date: December 2007	Page Count: 2
Revision/Date: 2, 6/11	

This supplement contains information necessary to ensure the accuracy of the above Instruction Sheet.

Change #1, 59513, 63065

In the **Symbols** Table delete CAT IV and add:

	Conforms to relevant South Korean EMC Standards
CAT II	Measurement Category II is applicable to test and measuring circuits connected directly to utilization points (socket outlets and similar points) of the low-voltage MAINS installation.
CAT III	Measurement Category III is applicable to test and measuring circuits connected to the distribution part of the building's low-voltage MAINS installation.
CAT IV	Measurement Category IV is applicable to test and measuring circuits connected at the source of the building's low-voltage MAINS installation.


In the **Specifications**, delete **Shock, Safety, EMI Regulations**, and **Certifications** and add:


IP Rating	IEC 60529: IP42
Safety	IEC 61010-1: 600 V CAT IV, Pollution Degree 2
Electromagnetic Environment	IEC 61326-1: Portable
Electromagnetic Compatibility	Applies to use in Korea only: Class A Equipment (Industrial Broadcasting & Communication Equipment)

[1]

- [1] This product meets requirements for industrial (Class A) electromagnetic wave equipment and the seller or user should take notice of it. This equipment is intended for use in business environments and is not to be used in homes.

Change #2, 67402

In the **Specifications** table, under **Function**  Check, add footnote [5]:

- [5] Minimum measureable input in  Check autorange is 3 V dc. For measurements below 3 V dc, push Range button twice to get to 6 V dc manual range.