Measuring incoming current

53.3°C Auto 59.4

1 29.3 AAC
2 28.3 AAC
3 29.6 AAC

19.0

1/13   11:08:31 AM

OR

Note: Use a wireless multimeter or a thermal imager. Both tools can not be used simultaneously to receive wireless measurements.

FLUKE *CNX 3000* WIRELESS MULTIMETER

Auto

V AC

0.0

1 29.3 A AC
2 28.3 A AC
3 29.6 A AC

HOLD   MINMAX   RANGE

SELECT