




4-Wire Earth Ground Resistance Tester Kit

Includes all hardware necessary to measure earth ground In 4 ranges from 2 to 2000Ω

Features:

- · 4-wire, 3-wire, and 2-wire testing
- Large dual line LCD
- Autoranging
- Automatic I (current) spike check
- Automatic P (potential) spike check
- Test Hold function for easy operation
- Automatic Zero adjustment
- AC Earth Voltage
- Data Hold and Auto Power off
- Overrange and low battery indication









sales@transcat.com

1.800.828.1470

EARTH RESISTANCE TESTER INSTRUCTIONS THE PROPERTY OF THE PROP

Ordering Information:

GRT3004-Wire Earth Ground Resistance Tester Kit GRT300-NISTL* ..GRT300 with Certificate Traceable to NIST 382153.....Replacement Earth Bars (2pk) **382154**.....Replacement Set of Leads

*Limited NIST for Certificate of Traceability to 4-wire mode only

Specifications	
Earth Ground Resistance ranges	$2\Omega'20\Omega'$ $200\Omega'2000\Omega$
Basic Accuracy	\pm (2%rdg+3d)
Resolution	$0.01\Omega' \ 0.1\Omega/1\Omega/0.01k\Omega$
Test Current / Frequency	<2mA / 820Hz
AC Earth Voltage / Frequency	0 to 300VAC / 40 to 500Hz
Accuracy	\pm (2%rdg+3d)
Power supply	Eight 1.5V 'AA' Batteries
Dimensions	9.8 x 7.8 x 4.3" (250 x 190 x 110mm)
Weight	3.15lbs (1430g) (batteries included)

